1st edition

HOBBS

MODEL 522 PEANUT COMBINE



PARTS CATALOG

HOBBS ENGINEERING CO. SUFFOLK, VA., U. S. A.

HOBBS

MODEL 522 PEANUT COMBINE
PARTS CATALOG
CONTENTS

	PAGE
HEADER SECTION	3
FRAME SECTION	5
WHEEL BEARING SECTION	7
COVER & SHIELD SECTION	9
FRONT CYLINDER SECTION	11
MIDDLE & REAR CYLINDER SECTION	13
CONCAVE & AUTOMATIC ADJUSTING SECTION	15
CLEANING FAN SECTION	17
CLEANING SHOE SECTION	19
STRAW RACK SECTION	21
STEMMER SECTION	23
PNEUMATIC CONVEYOR SECTION	25
BASKET SECTION	27
BASKET FRAME SECTION	29
DRIVE SECTION, LEFT SIDE	31
DRIVE SECTION, RIGHT SIDE	33
VINE SPREADER SECTION (OPTIONAL)	35
BAGGER ATTACHMENT (OPTIONAL)	37
NUMERICAL INDEX	38 , 39
WARRANTY	40

NOTE:

NOTE: The words "left" and "right" used in the description of parts should be taken as seen facing the direction of travel of the machine, unless otherwise noted. The "front" of the machine is the end which attaches to the tractor.

June 1973


DIRECTION OF TRAVEL
12
11
13
14
15
14
13
21
23
22
7
10
9
16
6
17
1
3
2
5
25
8
24
4
18
19
5
20

HEADER SECTION

No.	Part No.	Description	No. Req'd
1	9527	Frame, Header Assembly	1
2	12610	Band, Header	11
3	9528	Track, Roller	1
4	10050	Shaft	1
5	6099	Rotor, Bar Mounting	2
-	--	Keystock, ¼ x ¼ x 1½	2
6	6301	Header Bar, Left Mounted Spring Clip	2
7	6300	Header Bar, Right Mounted Spring Clip	2
8	12611	Cover, Header Drive Sprocket	1
9	6303	Retainer, Spring	24
10	7028	Spring, Header Pick-Up	24
11	6302	Clip, Spring Attaching	4
12	7014	Spring, Header Bar Expansion	4
13	3010	Bearing	4
14	--	Cap Screw, 5/8" - 11 x 1½", USS	4
15	1009	Pin, Bar Ass'y Mounting	8
16	--	Cotter Pin, 3/32" x 3/4"	8
17	--	Nut, 5/8" - 11 USS Hex	4
18	--	Set Screw, 3/8" - 16 x 1¼", USS Sq. Head	2
19	--	Nut, 3/8" - 16, USS Hex	2
20	3018	Bearing, 1-3/16" 3 Hole Flange	2
21	--	Washer, 5/8"	12
22	12887	Shoe Extension, Left Side	1
23	6258	Brace, Header Extension, Left	1
24	12888	Shoe Extension, Right Side	1
25	6259	Brace, Shoe Extension, Right	1


DIRECTION
OF TRAVEL
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

FRAME SECTION

No.	Part No.	Description	No. Req'd
1	9517-AA	Frame Section, Gearbox Mounting	1
2	9347	Frame Section, Front Side, Right	1
3	9346	Frame Section, Front Side, Left	1
4	9348	Axle	1
5	9349	Frame Middle Section, Left	1
6	9350	Frame Middle Section, Right	1
7	9351	Frame Section, Right Rear	1
8	9352	Frame Section, Left Rear	1
9	9523	Jack Stand	1
10	9501	Tongue Assembly	1
11	9513	Guard, Duct	1
12	9524	Support Bar, Top, Front & Rear	5
13	11012	Drive Ass'y, Complete PTO	1
14	11021	Shaft, Main Drive & Universal Joint	1
15	8021	Wheel, 9" x 24"	2
16	~~6201~~ 6221	Idler Mount and Adjusting Ass'y	1
17	9530	Coupler Ass'y, Hydraulic Hose	1
18	9531	Shield	1
19	3025	Bearing, 1-3/8", 3 Hole Flange	1
20	6063	Holder, Hydraulic Line	1
21	9532	Pad, Bearing Mtg.	2
22	7012	Spring, Jack Lift	1
23	6308	Spring Connector, Jack Stand	1
24	2050	Lock Pin, Universal Drive	1
25	9353	Support Bar, Top, Center	1
26	6310	Plate, Idler Mtg.	1
27	2020	Retainer, Idler Tightening Bolt	3
28	6135	Screw & Plate Ass'y, Drive Belt Idler	1
29	11022	Joint, Universal	1
30	1011	Nut, Acorn, 3/4" SAE	1
31	3059	Bearing	1
32	11050	Gearbox	1
33	6312	Idler Arm	1
34	6315	Link, Spring Connecting	1
35	7019	Spring	1
36	6055	Bolt Retainer, Drive Belt Idler	1
37	6064	Clamp, Hydraulic Line	2
38	3006	Bearing, 1-11/16", 4 Hole Flange	1
39	10058	Shaft, Gearbox Output	1
40	6261	Hydraulic Pump Mount, Right	1
41	6262	Hydraulic Pump Mount, Left	1
42	3020	Bearing with collar, 1-11/16", 4 Hole Flange	2
43	1013	Full Thread ½" x 2½" USS Bolt	1
44	9526	Angle Brace	1
	8022	900 x 24 rib implement tire	2
	8023	900 x 24 implement tube	2


1
2
3
4
5
6
7
8
9
10

WHEEL BEARING SECTION

No.	Part No.	Description	No. Req'd
1	8015	Seal	2
2	8013	Cone, Bearing, #25590	2
3	8012	Hub and Cup Ass'y	2
4	8017	Bolt, Lug	16
5	8014	Cone, Bearing, #25877	2
6	8018	Washer, Spindle	2
7	8019	Nut, Castle	2
8	8016	Cap, Hub	2
9	8039	Cup, Bearing Inner, (332) (25520)	1
10	8040	Cup, Bearing Outer, (~~14276~~)	1


10
9
8
12
8
14
7
16
18
3
7
7
29
30
31
1
11
13
15
17
32
6
5
4
2
24
27
28
26
19
24
28
20
21
33
22
25
23
DIRECTION
OF TRAVEL

COVER AND SHIELD SECTION

No.	Part No.	Description	No. Req'd
1	12892	Shield, Top Section	1
2	12881	Top, 1st Section	1
3	7024	Fastener, Spring Loaded	14
4	12889	Top, 2nd Section	1
5	12586	Top, 3rd Section	1
6	12890	Top, 4th Section	1
7	12891	Top, 5th & 6th ~~Section~~ & 7th section	3
8	12589	Top, Straw Rack, Cover Sections	2
9	12590	Top, Rear Section	1
10	12503	Hood	1
11	12877	Rear Straw Rack Side Cover, Right	1
12	12878	Rear Straw Rack Side Cover, Left	1
13	12875	Front Straw Rack Side Cover, Right	1
14	12876	Front Straw Rack Side Cover, Left	1
15	12873	Straw Rack Drive Side Cover, Right	1
16	12874	Straw Rack Drive Side Cover, Left	1
17	12869	Beater Cylinder Side Cover, Right	1
18	12870	Stripper Cylinder Side Cover, Left	1
19	12867	Bottom Side Cover, Right	1
--	12868	Bottom Side Cover, Left	1
20	12865	Lower Side Cover, Right	1
--	12866	Lower Side Cover, Left	1
21	12897	Shield, Cleaning Fan Drive	1
22	12514	Shield, Drive Belt, Rear	1
23	12895	Shield, Drive Belt, Front	1
24	6054	Bolt Retainer, Idler Tightener	2
25	12896	Shield, Header Drive	1
26	12883	Deflector	2
27	6198	Belt Adjustor, Frame Ass'y, Straw Rack Drive	1
28	6134	Belt Adjustor, Screw & Plate Ass'y	2
29	12894	Shield, Cylinder Drive Chain, Rear Section	1
30	12893	Shield, Cylinder Drive Chain, Front Section	1
31	6260	Brace, Cylinder Drive, Top Section	1
32	12880	Deflector, Light Chaff	1
33	~~3020~~ 3023	Bearing with collar, 1-11/16" 4 Hole Flange	2
34	10051	countershaft	1


DIRECTION
OF TRAVEL
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16

FRONT CYLINDER SECTION

No.	Part No.	Description	No. Req'd
1	5153	Head, Cylinder	2 1/pair
2	12832	Cylinder Section, Center	4
3	12833	Cylinder Section, Right	4
4	12834	Cylinder Section, Left	4
5	6169	Bar, Front Cylinder	8
6	6170	Vine Guide	17
7	12835	Frame Ass'y, Vine Guide	1
8	6047	Retainer, Picking Spring	40
9	7008	Spring, Picking	40
10	--	Screw, 7/16" - 14 x 2½" USS Cap	56
11	--	Lockwasher, 7/16"	56
12	--	Nut, 7/16" - 14 USS Hex	56
13	10102	Shaft, Front Cylinder	1
14	12836	Deflector	1
15	7003	Spring, Vine Guide Retaining	17
16	--	Keystock, 3/8 x 3/8 x 2½	2

(do not include the note when running new additions)

NOTE:

when no. 5153 is ordered it has to be specified which cylinder head the customer wants. The cylinder heads come in pairs but are not lefts & rights because it makes no difference which head goes on what side but the one that goes on the other side has to be the matching part. The direction which the keyway is pointing distinguishes the difference in the 2. If the keyway is pointing to a single hole its matching cylinder heads keyway has to be pointing to a double hole and vice versa.


25
4
23
26
DIRECTION OF TRAVEL
22
1
2
10
9
12
should be
20
21
19
18
24
3
11
16
8
7
6
5
13
14
15
17

MIDDLE AND REAR CYLINDER SECTION

No.	Part No.	Description	No. Req'd
1	5327	Head, Cylinder	4
2	6097	Bar, #2 Cylinder	10
3	6095	Bar, #1 Cylinder; for 5 Springs	5
4	10101	Shaft, Cleaning Shoe Oscillation Drive	1
5	10047	Shaft, #1 Cylinder	1
6	10103	Shaft, #2 Cylinder	1
7	3024	Bearing with collar, 1-11/16", 4 Hole Flange	4
8	3029	Collar, 1-11/16", Eccentric Locking	4
9	5329	Cylinder, Stripper	1
10	~~10054~~ 10123	Shaft, Stripper Cylinder	1
11	--	Nut, 7/16" - 14 USS Hex	40
12	--	Lockwasher, 7/16"	40
13	--	Screw, 7/16" - 14 x 2½" USS Cap	40
14	--	Nut, 7/16" - 14 USS Hex	100
15	--	Lockwasher, 7/16"	100
16	6047	Retainer, Picking Spring	100
17	--	Screw, 7/16" - 14 x 2½" USS Cap	100
18	7008	Spring, Picking	100
19	--	Nut, ½" - 13 USS Hex	4
20	--	Setscrew, ½" - 13 x 1¼" USS	4
21	--	Key, 3/8" x 2½"	4
22	3057	Bearing with collar, 1", 3 Hole Flange	4
23	12837	Deflector	1
24	6479	Bar, #1 Cylinder; for 5 Springs	5
25	2095	cleaning shoe drive shaft sleeve	1
26	120008	blade reinforcement	4


20
18
19
23
17
16
38
12
15
34
22
21
8
13
35
7
38
36
23
37
6
11
5
24
10
14
24
26
27
32
31
30
25
28
29
4
3
2
1
8
13
9
33
14
8
DIRECTION
OF TRAVEL

CONCAVE AND AUTOMATIC ADJUSTING SECTION

No.	Part No.	Description	No. Req'd
1	12823	Concave Screen, 1st Section	1
2	12824	Concave Screen, 2nd Section	1
3	12827	Frame Section, Concave Attaching, Middle Front	1
4	12825	Concave Screen, 3rd Section	1
5	12828	Frame, Concave Attaching, Middle Rear	1
6	12822	Separator, Concave Assembly	1
7	12826	Frame, Separator, Concave Attaching	1
8	6047	Retainer, Picking Spring	30
9	9516	Bar, Deflector Spring Mounting	1
10	6083	Crank Arm, Picking Control, Driven	1
11	2037	Spacer, Load Sensor Bar	2
12	6165-B	Shaft, Sensor Bar End (welds on after ass'y machine)	1
13	7018	Spring, Double Torsion, Straight Leg	20
14	7008	Spring, Double Torsion Crooked Leg, Picking	10
15	6165	Bar, Load Sensing Spring Mounting	1
16	7013	Spring, Picking, Control Adjusting	1
17	6094	Handle, Picking, Control Adjusting	1
18	9511	Stop, Control Handle	1
19	9512	Retainer, Control Handle Stop	1
20	6081	Quadrant, Control Handle Stop	1
21	6084	Board, Picking Control	1
22	6078	Shaft, Picking Control Board	1
23	2038	Spacer, Picking Control Board Shaft	2
24	2015	Spring Roll Pin, 1/4 x 1-3/4	2
25	6168	Link, Automatic Picking Control, Secondary	1
26	4076	Bushing, Control Cylinder Attaching	2
27	14006	Cylinder, Picking Control	1
28	6080	Link, Automatic Picking Control, Primary	1
29	7019	Spring, Automatic Adjusting Link Override	1
30	2042	Clevis Pin, 3/8" x 1-3/32"	1
31	6082	Crank Arm, Picking Control Drive	1
32	2041	Clevis, 3/8" SAE	1
33	6166	Bar, Picking Spring Mounting, Stationary	1
34	12829	Divider, Third Stage, Picking	1
35	6167	Bar, Divider Stiffening	1
36	12830	Divider, Second Stage, Picking	1
37	12831	Guard, Load Sensor	1
38	9525	Bar, Stripper	2


21
24
13
28
14
12
2
11
1
10
6
9
8
4
14
25
26
5
27
3
23
22
7
20
19
17
18
15
16
DIRECTION OF TRAVEL

CLEANING FAN SECTION

No.	Part No.	Description	No. Req'd
1	12534	Housing, Center Section	1
2	12530	Housing, End Section, Right	1
3	12531	Housing, End Section, Left	1
4	12532	Valve	1
5	6086	Shaft, Valve Control Rod	1
6	6087	Housing Mtg. Angle, Right	1
7	6088	Housing Mtg. Angle, Left	1
8	6089	Housing Mtg. Angle, Transverse	1
9	10110	Shaft, Cleaning Fan	1
10	5363	Rotor	1
11	--	Nut, 3/8" - 16 USS	4
12	--	Setscrew, 3/8" - 16 x 1", Square Head	4
13	12533	Blade, Cleaning Fan	6
14	3022	Bearing with collar, 1-3/16" Pillow Block	2
15	6111	Handle, Air Valve Adjusting	1
16	--	Nut, ¼" - 20, Wing	1
17	--	Setscrew, ¼" - 20 x 3/4", Square Head	1
18	12029	Quadrant, Air Valve Adjusting	1
19	6112	Lock, Air Valve Adjusting Handle	1
20	6092	Connector, Air Valve Control	1
21	--	Screw, 5/16" - 18 x 1", Cap	18
22	--	Pin, 1/8" x 1¼", Cotter	1
23	--	Screw, ¼" x 1", USS Cap	3
24	--	Nut, 5/16" - 18 UNC	36
25	--	Lockwasher, ¼"	3
26	--	Nut, ¼", USS	3
27	12898	Lip, Center Section Housing	Optional
28	--	Keystock, ¼ x ¼ x 1½	1


DIRECTION
OF TRAVEL
51
54
32
53
50
48
52
54
49
17
7
54
22
16
28
16
16
28
16
22
16
28
15
5
4
6
21
35
36
37
38
40
44
41
18
23
47
32
43
42
40
13
36
35
39
38
37
34
33
32
8
45
3
2
1
10
56
30
55
57
11
29
12
29
27
26
24
31
14
32
25
20
19
9
46

No.	Part No.	Description	No. Req'd
1	12612	Plate, Uncleaned Peanut Receiving	1
2	12613	Plate, Lower Air Channel	1
3	12614	Screen, Final Cleaning	1
4	12548	Plate, Chaff Accelerating	1
5	12852	Screening Finger Ass'y, No. 12 x 42-3/4"	1
6	12844	Tail Board, Adjusting Section	1
7	12845	Plate, Tail Board Bottom Section	1
8	12520	Side Frame Ass'y, Cleaning Tray, Right	1
9	12521	Side Frame Ass'y, Cleaning Tray, Left	1
10	12522	Frame Ass'y, Cleaning Tray, Front	1
11	10107	Shaft, Vibrating Screen Drive	1
12	12855	Plate, Cleaning Air Directing	1
13	12863	Trash Guard, Fixed, Right	1
14	12864	Trash Guard, Fixed, Left	1
15	12846	Plate, Air Direction Control, Front	1
16	12847	Plate, Air Lift Control	5
17	12862	Shield, Cleaning Air Interference	1
18	12850	Frame, Vibrating Screen, Right	1
19	12851	Frame, Vibrating Screen, Left	1
20	12842	Trash Guard, Vibrating Screen, Left	1
21	12843	Trash Guard, Vibrating Screen, Right	1
22	12848	Screening Finger Ass'y, Size 80, Odd	2
23	12853	Side Frame, Tail Board, Right	1
24	6076	Pitman, Vibrating Screen, Drive	1
25	6247	Cap, Rubber Bushing Retaining, with 5/16" hole	1
26	--	Nut, 5/8" - 18, SAE	1
27	3017	Bearing, 5/8" Rod End	1
28	12849	Screening Finger Ass'y, Size 80, Even	3
29	3056	Bearing, 1" Pillow Block	2
30	6069	Pitman Arm, Vibrating Screen, Drive	1
--	--	Keystock, ¼ x ¼ x 1½	1
31	12854	Side Frame, Tail Board, Left	1
32	4044	Rubber Bushing	11
33	6173	Hanger Bolt Ass'y	2
34	6174	Brace, Hanger Bolt Ass'y Arm	2
35	--	Screw, 1½ x ¼ - 20, Cap	4
36	--	Nut, 5/8", SAE Jam	4
37	4078	Nylon Bushing	4
38	--	Lockwasher, 5/8"	4
39	1029	Washer, 5/8" Flat	2
40	3061	Housing, Nylon Bushing	4
41	6114	Hanger, Vibrating Tray	2
42	1030	Spacer, ½" Bore x ½" long	2
43	--	Screw, 3½ x ½ - 20, Cap	2
44	1031	Washer, 5/8" Special	2
45	12871	Plate, Material Guide, Right	1
46	12872	Plate, Material Guide, Left	1
47	2083	Lock, Tail Board Adjustment	2
48	12504	Tray, Material Conveying, Rear	1
49	6049	Frame, Tray Support, Right	1
50	6050	Frame, Tray Support, Left	1
51	6304	Hanger, Material Conveying Tray, Rear	1
52	6051	Hanger, Material Conveying Tray, Right	1
53	6053	Hanger, Material Conveying Tray, Left	1
54	9418-C	Cap, Rubber Bushing Retaining	6
55	6433	Angle, Curtain Mounting	1
56	6195	Strip, Curtain Retaining	1
57	4189	Curtain	1


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
DIRECTION OF TRAVEL

STRAW RACK SECTION

No.	Part No.	Description	No. Req'd
1	12838	Straw Rack Ass'y, No. 2 & No. 4	2
2	10105	Shaft, Straw Rack Rock, Straight	1
3	10106	Shaft, Straw Rack Rock, Offset	1
4	6172	Pitman, Straw Rack Drive	2
-	--	Keystock, 3/8 x 3/8 x 2½	2
5	3062	Bearing, 1-7/16", 3 Hole Flange	2
6	9354	Frame, Straw Rack Hanger	1
7	1032	Sleeve, Rubber Bushing Insert	2
8	12840	Plate, Straw Rack Hanger	4
9	6305	Hinge Ass'y, Upper Right & Lower Left	8
10	6306	Hinge Ass'y, Upper Left & Lower Right	8
11	--	Washer, ¼" Flat	48
12	6046	Leaf, Straw Rack Hinge	32
13	4078	Bearing, Straw Rack Hinge, Nylon	32
14	3017	Bearing, 5/8" Rod End	2
15	--	Nut, 5/8" - 18 SAE	2
16	6074	Pitman, Straw Rack Drive, Right	1
17	6247	Cap, Rubber Bushing Retaining, with 5/16" Hole	2
18	12841	Pan, Straw Rack Attachment, Rear	4
19	12839	Straw Rack Ass'y, No. 1 & No. 3	2
20	4044	Bushing, Rubber	8
21	3058	Bearing, 1-3/16" 3 Hole Flange	2
22	~~3023~~ 3020	Bearing, 1-11/16" 4 Hole Flange	2
23	6171	Bar, Straw Rack Attachment, Front	4
24	2081	Spacer, Straw Rack Hinge	8
25	10104	Shaft, Straw Rack Pitman Drive	1
26	6073	Pitman, Straw Rack Drive, Left	1
27	--	Nut, ¼" - 20 USS	32
28	--	Screw, ¼" - 20 x 3" USS Cap	16
29	2082	Sleeve, Straw Rack Pitman Drive	1

Note: To distinguish the difference in where the straw racks are to be located, stand behind machine and count from left to right, this will give the correct positioning of the racks.


DIRECTION
OF TRAVEL
25
15
16
13
14
15
16
15
16
14
34
27
3
34
15
16
9
5
7
23
24
18
31
20
32
19
4
33
8
2
6
16
10
36
26
33
31
1
38
39
20
21
22
17
11
10
33
12
36
35
16
26
37
30
29
28
33

No.	Part No.	Description	No. Req'd
1	12861	Hopper, Stemmer Discharge	1
2	12860	Deflector	1
3	2052	Locator	2
4	12856	Stemmer Bottom	1
5	12857	Plate, Stemmer Attaching	1
6	12858	Side Frame, Stemmer, Right	1
7	12859	Side Frame, Stemmer, Left	1
8	6176	Bracket, Stemmer Hanger Mounting, Right	1
9	6177	Bracket, Stemmer Hanger Mounting, Left	1
10	6175	Bar Ass'y, Stemmer Hanger Mounting	2
11	10108	Shaft, Stemmer Saw, Rear	1
12	10044	Shaft and Hanger Ass'y	1
13	6071	Hanger Ass'y, Stemmer Box, Rear	1
14	6072	Spacer	4
15	9418-C	Cap, Rubber Bushing Retaining	8
16	4044	Bushing, Rubber	16
17	3016	Bearing, 7/8" Pillow Block	2
18	6180	Pitman, Cleaning Shoe Drive, Left	1
19	6196	Adjustment, Stemmer Saw	1
20	9502	Guide, Stemmer Saw	2
21	6179	Bracket, Stemmer Saw Mounting, Front	1
22	6184	Pitman, Cleaning Shoe Drive, Right	1
23	--	Nut, 5/8" SAE	2
24	3017	Bearing, 5/8" Rod End	2
25	6316	Hanger Ass'y, Cleaning Shoe, Rear	1
26	6048	Pitman Arm, Cleaning Shoe Drive	2
--	--	Keystock, ¼ x ¼ x 2½	2
27	4076	Bushing, Stemmer Hanger Support	4
28	5150	Saw, 72 Tooth Stemmer	74
29	--	Nut, 1" SAE Castle	2
30	2076	Spacer, Stemmer Saw	78
31	6178	Bracket, Stemmer Saw Mounting, Rear	2
32	3008	Bearing with collar, 1" Pillow Block	2
33	6247	Cap, Rubber Bushing Retaining, with 5/16" Hole	6
34	2053	Retainer	4
35	10109	Shaft, Stemmer Saw, Front	1
36	1032	Sleeve, Rubber Bushing Insert	2
37	3022	Bearing, 1-3/16" Pillow Block	2
38	12942	Cover, Inspection	1
39	--	Nut, ¼ - 20 x 3/4" Long Wing	2


1
2
33
34
35
36
3
29
31
37
28
30
27
2
23
5
41
39
8
15
22
23
40
24
25
26
20
9
32
7
21
14
13
11
12
18
16
17
10
DIRECTION OF TRAVEL
38
19
42
6
24
4

PNEUMATIC CONVEYOR SECTION

No.	Part No.	Description	No. Req'd
1	12819	Nozzle, Conveyor Duct	1
2	12817	Conveyor Pipe, Curved Section	2
3	12818	Conveyor Pipe, Straight Section	1
4	12816	Plate, Inspection	1
5	12806	Conveyor Pipe with Cleanout Door	1
-	--	Chain, 3 Link Check	2
-	--	Cotter Pin, 3/16" x 2"	4
6	12805	Pipe, High Pressure Curved Section	1
7	12804	Pipe, High Pressure Blower Connecting	1
8	12802	Housing, Bearing Mounting Side	1
9	12807	Side Panel, Jet Tunnel, Left	1
10	12808	Side Panel, Jet Tunnel, Right	1
11	12815	Bottom Panel, Jet Tunnel	1
12	12508	Cover Plate, Jet Tunnel, High Pressure End	1
13	12810	Cover Plate, Jet Tunnel, Low Pressure End	1
14	12509	Hopper, Pneumatic Conveyor	1
15	6162	Rod, Air Volume Control	1
16	12811	Plate, Primary Jet Section	1
17	12812	Plate, Secondary Jet Adjustable Section	1
18	12809	Plate, Primary Jet Housing, Top	1
19	12570	Connector, High Pressure Pipe Connecting	1
20	12813	Valve, Check and Venturi Control	1
21	12814	Valve, Jet Air Volume Control	1
22	6163	Crank Arm, Air Volume Control Valve	1
23	2003	Clevis	2
--	2009	Pin, Clevis	2
--	--	Cotter Pin, 1½" x 1/8"	2
24	6158	Bracket, Pneumatic Conveyor Supporting, Front	2
25	10100	Shaft, Blower Rotor	1
26	3057	Bearing with collar, 1" 3 Hole Flange	1
27	6156	Brace, Blower Mounting, Primary	1
28	6155	Brace, Blower Mounting, Secondary	1
29	3008	Bearing, 1" Pillow Block	1
30	12803	Rotor	1
--	--	Keystock, ¼ x ¼ x 3½	1
31	5036	V-Sheave, 1B4.0, with 1" Bore	1
32	6161	Connector, Jet Tunnel Outlet	1
33	12579	Duct Brace, Rearward, Upper Section	1
34	12578	Duct Brace, Rearward, Lower Section	1
35	12577	Duct Brace, Forward, Upper Section	1
36	12576	Duct Brace, Forward, Lower Section	1
37	12801	Housing and Attaching Frame Ass'y	1
38	6157	Bracket, High Pressure Pipe Mounting, Rear	1
39	6159	Quadrant and Bracket Ass'y	1
40	6181	Hinge Pin and Control Handle Lock Ass'y	1
41	6160	Handle, Jet Air Volume Control	1
--	--	Washer, ½" Flat	1
--	--	Cotter Pin, 2" x 3/16"	1
42	6263	Stop, Air Volume Control Valve	1

Note: Direction of travel, only on this page, indicates direction of material flow.


DIRECTION OF TRAVEL
18
17
21
20
9
7
2
14
15
16
1
4
3
5
13
12
22
11
8
12
13
23
10
19
6

BASKET SECTION

No.	Part No.	Description	No. Req'd
1	12538	Top, Lid Attaching Section	1
2	12539	Top, Duct Inlet Section	1
3	12537	Plate, Duct Inlet Side	1
4	12543	Plate, Bottom Housing Section	1
5	12540	Plate, Bottom Housing Discharge	1
6	12542	Side Ass'y, Front	1
7	12541	Side Ass'y, Rear	1
8	12544	Lid, Basket Dumping	1
9	12536	Duct, Spent Air Discharge	1
10	12535	Duct and Screen Ass'y	1
11	9509	Bar, Bin Hinge	1
12	9508-B	Spacer, Bin Hinge	2
13	9508	Shaft, Bin Hinge	2
14	12820	Pipe, Bin Inlet	1
15	6182	Brace	1
16	12555	Stiffener, Bin Housing	1
17	12884	Screen Ass'y, Dirt Removal	1
18	12551	End Section, Bin Lip, Right	1
19	12552	End Section, Bin Lip, Left	1
20	12545	Bottom Section, Bin Lip	1
21	12546	Stiffener, Basket Spout	1
22	1008	Pin, Hinge	3
23	12885	Sandtrap Ass'y	1


8
7
1
8
12
6
3
4
2
9
8
7
8
13
11
10
8
7
8
15
14
5
8
7
6
13
8

BASKET FRAME SECTION

No.	Part No.	Description	No. Req'd
1	9514	Side Frame Ass'y, Left	1
2	9507	Side Frame Ass'y, Right	1
3	9505	Brace, Flat Section	1
4	9506	Brace, Angle Section	1
5	9515	Bar, Bin Frame Connector	1
6	14000	Cylinder, Hydraulic	2
7	2039	Pin, Cylinder Att'g	4
8	2040	Clip, Pin Retaining	8
9	14002	Hydraulic Hose, ¼" x 24" Long	1
10	14001	Hydraulic Hose, 3/8", 142" Long	2
11	9510	Manifold, Hydraulic Oil Distribution	1
12	14003	Hydraulic Hose, ¼", 30" Long	1
13	2016	Washer, Hydraulic Spacer	4
14	14005	Hydraulic Hose, ¼", 92" Long	1
15	14004	Hydraulic Hose, ¼", 104" Long	1
--	2046	Adapter, ¼" Swivel	2
--	2047	Adapter, ¼" - 45° Swivel	2
--	2048	Bushing, 3/8" - ¼" Reducing	4
--	2045	Adapter, 3/8" Swivel	2


15 (INNER SHEAVE)
14 (OUTER SHEAVE)
18
4
7
17
8
23
16
19
13
13
13
1
24
20
12
21
2
3
22
5
6
9
10
11

DRIVE SECTION, LEFT SIDE

No.	Part No.	Description	No. Req'd
1	5113	Sprocket, 60B60, with 1-11/16" Bore	1
-	3020	Bearing with Collar, 1-11/16", 4 Hole Flange	1
-	--	Keystock, 3/8 x 3/8 x 1-3/4	1
2	5114	Sprocket, 60B26, with 1-11/16" Bore	1
-	3020	Bearing with Collar, 1-11/16", 4 Hole Flange	1
3	5152	Sprocket, 60B19, with 1-11/16" Bore	1
-	--	Keystock, 3/8 x 3/8 x 3½	1
4	5209	Idler, 4" Chain, with tire	1
-	2080	Spacer, 3/4" Idler	1
5	5209	Idler, 4" Chain, with tire	1
-	2035	Spacer, 2¼"	1
6	5209	Idler, 4" Chain, with tire	1
-	2031	Spacer, 3/8"	1
7	5113	Sprocket, 60B60, with 1-11/16" Bore	1
8	5119	Sprocket, 60B60, with 1-11/16" Bore w/Tapped Ecc. Hole	1
-	3024	Bearing with Collar, 1-11/16", 4 Hole Flange	1
-	--	Keystock, 3/8 x 3/8 x 1-3/4	1
9	5207	Idler, 4" V-Belt	1
-	2032	Spacer, 7/16"	1
10	5055	V-Sheave, 1B6.0, with 1" bore	1
--	3008	Bearing with Collar, 1" Pillow Block	1
--	--	Keystock, ¼ x ¼ x 1½	1
11	5055	V-Sheave, 1B6.0, with 1" Bore	1
--	3008	Bearing with Collar, 1" Pillow Block	1
--	--	Keystock, ¼ x ¼ x 1½	1
12	5509	V-Sheave, 1B8.75, with 1" Bore	1
--	3015	Bearing with Collar, 1" Two Hole Flange	2
13	5317	Idler, 3" Flat Belt (Vine Spreader, only)	3
14	5510	V-Sheave, 1B8.75, with 1-7/16" Bore with Eccentric	1
--	--	Keystock, 5/16 x 5/16 x 3	1
15	5507	V-Sheave, 1B7.8, with 1-7/16" Bore	1
--	3062	Bearing, 1-7/16", 3 Hole Flange	1
16	5209	Idler, 4" Chain, with tire	1
--	2034	Spacer, 1"	1
17	5209	Idler, 4" Chain, with tire	1
--	2078	Spacer, 17/32"	1
18	5209	Idler, 4" Chain, with tire	1
--	2078	Spacer, 17/32"	1
19	5133	Sprocket, 60B16, with 1-11/16" Bore	1
--	3024	Bearing with Collar, 1-11/16", 4 Hole Flange	1
--	--	Keystock, 3/8 x 3/8 x 3½	1
20	4179	V-Belt, B158 (Vine Spreader Drive)	1
21	4184	V-Belt, BB128, (Stemmer Saw Drive)	1
22	4186	Chain, #60, 172 Pitches Long	1
23	4187	Chain, #60, 137 Pitches Long	1
24	4188	Chain, #60, 103 Pitches Long	1


12
13
30
11
9
10
28
8
7
5
3
2
1
25
23
24
4
22
27
6
26
20
21
17
18
19
16
15
29
14

No.	Part No.	Description	No. Req'd
1	14050	Pump, Hydraulic (Optional)	1
2	5089	V-Sheave, 1B6.3, with 3/4" Bore	1
3	5205	Belt Idler, 4" Single Flange Flat	1
4	5210	Belt Idler Ass'y, 2 Section Special Flat, w/Spacer	1
5	5209	Idler, 4" Chain, with tire	1
-	2079	Spacer, 5/8"	1
6	5211	Belt Idler Ass'y, 2 Piece Special Flat	1
-	2077	Spacer, ½"	1
7	5151	Sprocket, 40B48, with 1-11/16" Bore	1
-	3020	Bearing with Collar, 1-11/16", 4 Hole Flange	1
-	--	Keystock, 5/16 x 5/16 x 1-3/4	1
8	5209	Idler, 4" Chain, with tire	1
-	2079	Spacer, 5/8"	1
9	5142	V-Sheave, 2B9.75, with 1-11/16" Bore w/Eccentric	1
-	3024	Bearing with Collar, 1-11/16", 4 Hole Flange	1
-	--	Keystock, 3/8 x 3/8 x 1½	1
10	5500	V-Sheave, 2B3.4P.D., with 1" Bore	1
--	3057	Bearing with Collar, 1", 3 Hole Flange	1
--	--	Keystock, ¼ x ¼ x 2¼	1
11	5211	Belt Idler Ass'y, 2 Piece Special Flat	1
12	5504	V-Sheave, 2B8.75, with 1-7/16" Bore w/Eccentric	1
--	3062	Bearing, 1-7/16", 3 Hole Flange	1
--	--	Keystock, 5/16 x 5/16 x 1-3/4	1
13	5501	V-Sheave, 2B5.1, with 1" Bore	1
--	3057	Bearing with Collar, 1", 3 Hole Flange	1
--	--	Keystock, ¼ x ¼ x 2¼	1
14	5036	V-Sheave, 1B4.0, with 1" Bore	1
--	3008	Bearing, 1" Pillow Block	1
--	--	Keystock, ¼ x ¼ x 1½	1
15	5205	Idler, 4" Flat Belt	1
--	2031	Spacer, 3/8"	1
16	5207	Idler, 4" V-Belt	1
17	5053	V-Sheave, 1B11.8	1
--	5025	Bushing, 1-3/16" FT	1
--	3022	Bearing with Collar, 1-3/16" Pillow Block	1
18	5508	V-Sheave, 1C8.0	1
--	5010	Bushing, 1-3/16" SDS	1
--	--	Keystock, ¼ x ¼ x 2½	1
19	5208	Idler, 6" Flat Belt	1
20	5505	V-Sheave, 1C20.0	1
--	5506	Bushing, 1-11/16" QD	1
--	3020	Bearing with Collar, 1-11/16", 4 Hole Flange	1
--	--	Keystock, 3/8 x 3/8 x 5	1
21	5051	V-Sheave, 2C16.0, with 1-11/16" Bore	1
22	5154	Sprocket, 40B32, with 1-3/16" Bore	1
--	3018	Bearing, 1-3/16", 3 Hole Flange	1
--	--	Keystock, ¼ x ¼ x 1½	1
23	5088	V-Sheave, 1B11.0	1
--	5060	Bushing, 1-11/16" SDS	1
--	3006	Bearing, 1-11/16", 4 Hole Flange	1
--	--	Keystock, 3/8 x 3/8 x 1-3/4	1
24	5050	V-Sheave, 2C10.0, with 1-11/16" Bore	1
--	--	Keystock, 3/8 x 3/8 x 3	1
25	4185	V-Belt (Pump Drive)	1
26	4066	V-Belt, C144 (Main Drive)	2
27	4183	Chain, #40, Double Pitch 254 Pitch Length	1
28	4180	V-Belt, C112 (Cleaning Fan Drive)	1
29	4001	V-Belt, B128 (Pneumatic Conveyor Drive)	1
30	4069	V-Belt, B136 (Straw Rack Drive)	2


19
12
21
11
20
11
21
12
19
9
9
9
9
22
22
1
7
8
3
4
5
6
10
16
13
14
18
14
14
18
18
16
17
16
15
2

VINE SPREADER SECTION

No.	Part No.	Description	No. Req'd
1	12886	Shield	1
2	6189	Spacer	1
3	5326	Hub, Rotor	1
4	6257	Arm, Rotor	4
5	4074	Flail	4
6	6118	Clamp, Flail Retaining	4
7	9355	Frame Ass'y	1
8	10040	Shaft, Flail Rotor	1
9	3015	Bearing with collar, 1" Two Hole Flange	4
10	10111	Driveshaft	1
11	11023A	Yoke, Universal Joint	2
12	11023B	Yoke, Universal Joint	2
13	6317	Bracket, Idler Mounting Fixed Section	1
14	--	Cap Screw, 3/8" - 16 x 1¼" USS	3
15	9146	Frame, Idler Mounting	1
16	--	Nut, 3/8" - 16 USS	3
17	9152	Bracket, Idler Mounting Adjustable Section	1
18	5317	Idler, 3" Flat Belt	3
19	2092	Bushing	2
20	10112	Shaft, Universal Joint Coupling	1
21	11005	Spider Journal	2
22	11023	Complete Universal Ass'y	2


DIRECTION
OF TRAVEL
20
22
21
23
19
24
18
17
16
15
7
2
5
6
14
26
13
12
11
10
9
8
1
25

BAGGER ATTACHMENT

No.	Part No.	Description	No. Req'd
1	12934	Door, Bagging Stand	1
2	12935	Stand, Bagging	1
3	6468	Valve, Bag Filler	1
4	12912	Ass'y, Bag Filler	1
5	6475	Angle, Extension	1
6	6476	Angle, Mtg. (weld to side of combine)	1
7	4205	Chain, 3/16" Attaching; 36 links	2
8	--	Pin, Cotter; 1¼" Long x 3/16"	1
9	--	Chain, Check; 7 Link	1
10	--	Pin, Cotter; 5/8" Long x 3/16"	1
11	~~6467~~ 6515	Handle, Adjusting	1
12	12916	Plate, Left Side Reinforcing	1
13	6466	Valve, Directional Flow	1
14	~~2091~~ 12941	~~Washer, Special~~ PIPE, EXTENSION CONVEYOR	~~2~~ 1
15	12917	Pipe, Intersecting Conveyor	1
16	12918	Pipe, Bypass Conveyor	1
17	12915	Plate, Right Side Reinforcing	1
18	12913	Pipe, Tapered Conveyor	1
19	12914	Screen, Trash Separation	1
20	~~12919~~ 120010	Pipe, Discharge ~~Conveyor~~	1
21	12938	Mount, Hopper	1
22	~~12936~~ 120009	Shield, Left Front Chain	1
23	12937	Shield, Left Rear Chain	1
24	--	Washer, ½" Flat	2
25	12939	Pipe, Large Curved Conveyor	1
~~26~~	~~12941~~	~~Pipe, Extension Conveyor~~	~~1~~

Note: When a basket and a bagger attachment are installed on the same machine do not use part numbers 25 & ~~26~~ 14. When only a bagger attachment is used it is not necessary to use parts 8 - ~~17~~ 13 & 15-17

NUMERICAL PARTS INDEX

Part No.	Page
1008	27
1009	3
1011	5
1013	5
1029	19
1030	19
1031	19
1032	21,23
2033	25
2009	25
2015	15
2016	29
2020	5
2031	31,33
2032	31
2034	31
2035	31
2037	15
2038	15
2039	29
2040	29
2041	15
2042	15
2045	29
2046	29
2047	29
2048	29
2050	5
2052	23
2052	23
2076	23
2077	33
2078	31
2079	33
2080	31
2081	21
2082	21
2083	19
~~2091~~	~~37~~
2092 2095	35 13
3006	5,33
3008	23,25
	31,33
3010	3
3015	31,35
3016	23
3017	19,21
	23
3018	3,33
3020	5,31,33,21
3022	17,23,33
3023	9 23
3024	13,31,33
3025	5
3029	13
3056	19
3057	13,25,33
3058	21
3059	5
3061	19
3062	21,31,33
4001	33
4044	19,21,23
4066	33
4069	33
4074	35
4076	15,23
4078	19,21
4179	31
4180	33
4183	33
4184	31
4185	33
4186	31
4187	31
4188	31
4189	19
4205	37
5025	33
5036	25,33
5050	33
5051	33
5053	33
5055	31
5060	33
5088	33
5089	33
5113	31
5114	31
5119	31
5133	31
5142	33
5150	23
5151	33
5152	31
5153	11
5154	33
5205	33
5207	31,33
5208	33
5209	31,33
5210	33
5211	33
5317	31,35
5326	35
5327	13
5329	13
5363	17
5500	33
5501	33
5504	33
5505	33
5506	33
5507	31
5508	33
5509	31
5510	31
6046	21
6047	11,13,15
6048	23
6049	19
6050	19
6051	19
6053	19
6054	9
6055	5
6063	5
6064	5
6069	19
6071	23
6072	23
6073	21
6076	19
6078	15
6080	15
6081	15
6082	15
6083	15
6084	15
6086	17
6087	17
6088	17
6089	17
6092	17
6094	15
6095	13
6097	13
6099	3
6111	17
6112	17
6114	19
6118	35
6134	9
6135	5
6155	25
6156	25
6157	25
6158	25
6159	25
6160	25
6161	25
6162	25
6163	25
6165	15
6165B	15
6166	15
6167	15
6168	15
6169	11
6170	11
6171	21
6172	21
6173	19
6174	19
6175	23
6176	23
6177	23
6178	23
6179	23
6180	23
6181	25
6182	27
6184	23
6189	35
6195	19
6196	23
6198	9
~~6201~~ 6221	5
6247	19,21,23
6257	35
6258	3
6259	3
6260	9
6261	5
6262	5
6263	25
6300	3
6301	3
6302	3
6303	3
6304	19
6305	21
6306	21
6308	5
6310	5
6312	5
6315	5
6316	23
6317	35
6433	19
6466	37
~~6467~~	~~37~~
6468	37
6475	37
6476	37
6479 6515	13 37
7003	11
7008	11,13,15
7012	5
7013	15
7014	3
7018	15
7019	5,15
7024	9
7028	3
8012	7
8013	7
8014	7
8015	7
8016	7
8017	7
8018	7
8019	7
8021 8022 8023	5 7
8039	7
8040	7
9146	35
9152	35
9346	5
9347	5
9348	5
9349	5
9350	5
9351	5
9352	5
9353	5
9354	21
9355	35
9418C	19,23
9501	5
9502	23
9505	29
9506	29
9507	29
9508	27
9508B	27
9509	27
9510	29
9511	15
9512	15
9513	5
9514	29
9515	29
9516	15
9517AA	5
9523	5
9524	5
9525	15
9526	5
9527	3
9528	3
9530	5
9531	5
9532	5
10040	35
10044	23
10047	13
10050	3
~~10054~~ 10051	~~13~~ 9
10058	5

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
10100	25	12589	9	12850	19	12935	37
10101	13	12590	9	12851	19	~~12936~~	~~37~~
10102	11	12610	3	12852	19	12937	37
10103	13	12611	3	12853	19	12938	37
10104	21	12612	19	12854	19	12941	37
10105	21	12613	19	12855	19	12942	23
10106	21	12614	19	12856	23	14000	29
10107	19	12801	25	12857	23	14001	29
10108	23	12802	25	12858	23	14002	29
10109	23	12803	25	12859	23	14003	29
10110	17	12804	25	12860	23	14004	29
10111	35	12805	25	12861	23	14005	29
10112 10123	35 13	12806	25	12862	19	14006	15
11012	5	12807	25	12863	19	14050	33
11021	5	12808	25	12864	19	120008	13
11022	5	12809	25	12865	9	120009 120010	37 37
11023	35	12810	25	12866	9		
11023B	35	12811	25	12867	9		
11050	5	12812	25	12868	9		
12029	17	12813	25	12869	9		
12503	9	12814	25	12870	9		
12504	19	12815	25	12871	19		
12508	25	12816	25	12872	19		
12509	25	12817	25	12873	9		
12514	9	12818	25	12874	9		
12520	19	12819	25	12875	9		
12521	19	12820	27	12976	9		
12522	19	12822	15	12877	9		
12530	17	12823	15	12878	9		
12531	17	12824	15	12880	9		
12532	17	12825	15	12881	9		
12533	17	12826	15	12883	9		
12534	17	12827	15	12884	27		
12535	27	12828	15	12885	27		
12536	27	12829	15	12886	35		
12537	27	12830	15	12887	3		
12538	27	12831	15	12888	3		
12539	27	12832	11	12889	9		
12540	27	12833	11	12890	9		
12541	27	12834	11	12891	9		
12542	27	12835	11	12892	9		
12543	27	12836	11	12893	9		
12544	27	12837	13	12894	9		
12545	27	12838	21	12895	9		
12546	27	12839	21	12896	9		
12548	19	12840	21	12897	9		
12551	27	12841	21	12912	37		
12552	27	12842	19	12913	37		
12555	27	12843	19	12914	37		
12570	25	12844	19	12915	37		
12576	25	12845	19	12916	37		
12577	25	12846	19	12917	37		
12578	25	12847	19	12918	37		
12579	25	12848	19	~~12919~~	~~37~~		
12586	9	12849	19	12934	37		

WARRANTY

Hobbs Engineering Company warrants that each machine manufactured by it and sold under the HOBBS trademark shall be free from defects in material and workmanship. The Company's sole obligation under this warranty shall be limited to making good, F. O. B. Company factory, any part of its product which under normal and proper use and maintenance proves defective in material and workmanship within six months after delivery to the Buyer provided that notice of such defect and satisfactory proof thereof is promptly given by the Buyer through his Dealer to the Company, and thereafter such part is returned to the Company, with transportation charges prepaid, and Company's examination proves such part to have been defective.

This warranty does not apply in respect to damage to any product or accessory or attachment thereof caused by overloading or other misuse, neglect or accident nor does this warranty apply to any product, or accessory or attachment thereof which shall have been repaired or altered by other than the Company or its authorized dealer in any way, which, in the sole judgment of the Company affects the performance, stability or purpose for which it was manufactured.

With respect to tires, engines, or other trade accessories, the Company makes no warranty whatsover and the buyer shall rely solely upon the existing warranties, if any, of the respective manufacturers thereof.

IMPROVEMENTS

Hobbs Engineering Company is constantly striving to improve its machines. Changes in design and improvement will be made whenever the manufacturer believes the efficiency of the machines will be improved thereby, but without incurring any obligation to incorporate such improvements in any machines which have been shipped or are in service.